

Process Used to Retrofit the Pivot Shoe Operator



1. Existing window – standard pivot shoe



2. Remove tacks from vent



3. Remove operator



4. Install gasket on pivot shoe



5. Install pivot shoe with SS Arms



6. Attach pivot shoe with fasteners



7. Attach tracks to vent