



Series 350-T / Series 450-T

Screen Clip Installation Instructions

Installation:

Step #1 – Insert the clip into the t-slot groove as shown in Figure #1 (weather strip was not shown to improve clarity).

Step #2 – Rotate screen clip as shown in Figure #2.

Step #3 – As you continue rotating the screen clip it will snap into place as shown in Figure #3.

DO NOT SLIDE SCREEN CLIP ON THE EXTRUSION! Sliding of the screen clip may damage the finish of the window.

Recommended Locations (locations may be adjusted per screen configuration and size):

Awning Windows – 1 clip centered on each jamb and 2 clips at head 6" from the ends.

Casement Windows – 1 clip centered on each jamb and 2 clips at head 6" from the ends.

Hopper Windows – 2 clips at head 6" from the ends and 2 clips at sill 6" from the ends.

(2 additional screen clips provided for large screen configurations)

Figure #1



Figure #2



Figure #3



DOC: Screen Clip Installation Instructions

Rev: B

Date: 05/18/22



Series 350-T / Series 450-T

Screen Clip Installation Instructions

Installation:

Step #1 – Insert the clip into the t-slot groove as shown in Figure #1 (weather strip was not shown to improve clarity).

Step #2 – Rotate screen clip as shown in Figure #2.

Step #3 – As you continue rotating the screen clip it will snap into place as shown in Figure #3.

DO NOT SLIDE SCREEN CLIP ON THE EXTRUSION! Sliding of the screen clip may damage the finish of the window.

Recommended Locations (locations may be adjusted per screen configuration and size):

Awning Windows – 1 clip centered on each jamb and 2 clips at head 6" from the ends.

Casement Windows – 1 clip centered on each jamb and 2 clips at head 6" from the ends.

Hopper Windows – 2 clips at head 6" from the ends and 2 clips at sill 6" from the ends.

(2 additional screen clips provided for large screen configurations)

Figure #1



Figure #2



Figure #3



DOC: Screen Clip Installation Instructions

Rev: B

Date: 05/18/22