

**GREATER THAN 90° INSIDE CORNER WINDOW:
BLOCK FRAMES**

250-T, 450-T, 530-T, 3800-T & 4800-T

U:\Cadfiles_Admin\Products\Windows


CUSTOMER:

ORDER NO.:


SERIES:

ITEM NO.:

PLAN VIEW
SERIES 250-T SHOWN



ISOMETRIC VIEW
GREATER THAN 90°
INSIDE CORNER STRUCTURE



CUSTOMER TO FILL IN

D ANGLE: _____

†IMPORTANT: 450-T SHIM SPACE VARIES

INSTRUCTIONS: ENTER THE (3) R.O. DIMENSIONS AND (1) ANGLE IN THE TABLES. **ENTER BUILDING EXTERIOR DIMENSIONS ONLY!**

♦SEE FORMULA BELOW TO CALCULATE *SERIES ADD

CUSTOMER TO FILL IN		FLEETWOOD TO FILL IN		
DIM. REF.	CUSTOMER R.O.	*SERIES ADD AND (C) SHIM DEDUCT		LONG POINT (INT.) N.F.D.
A		+	*	=
B		+	*	=
C		-	.50 [†]	=

SERIES	**FRAME DEPTH
250-T	2.25
450-T [†]	3.00
530-T	3.375
3800-T	4.50
4800-T	5.75

♦*SERIES ADD = TAN[90-D/2](**FRAME DEPTH)-(1/4" SHIM)

CUSTOMER SIGNATURE:

DATE: