


CUSTOMER:

ORDER NO.:


SERIES:

ITEM NO.:

**PLAN VIEW
SERIES 250-T SHOWN**



**ISOMETRIC VIEW
LESS THAN 90°
INSIDE CORNER STRUCTURE**



CUSTOMER TO FILL IN

D ANGLE: _____

†IMPORTANT: 450-T SHIM SPACE VARIES

**INSTRUCTIONS: ENTER THE (3) R.O. DIMENSIONS AND (1) ANGLE
IN THE TABLES. ENTER BUILDING EXTERIOR DIMENSIONS ONLY!**

➤SEE FORMULA BELOW
TO CALCULATE
*SERIES ADD

CUSTOMER TO FILL IN		FLEETWOOD TO FILL IN	
DIM. REF.	CUSTOMER R.O.	*SERIES ADD AND (C) SHIM DEDUCT	LONG POINT (INT.) N.F.D.
A		+ *	=
B		+ *	=
C		- .50†	=

SERIES	**FRAME DEPTH
250-T	2.25
450-T†	3.00
530-T	3.375
3800-T	4.50
4800-T	5.75

➤*SERIES ADD = $\tan[90-D/2](**FRAME DEPTH)-(1/4" SHIM)$

CUSTOMER SIGNATURE:

DATE: